

PIECE OF CEMCO STUD OR TRACK  
WEB STIFFENER, 3/8" SHORTER  
THAN DEPTH OF JOIST AS REQUIRED  
BY BUILDING CODE OR E.O.R.

ATTACH WEB STIFFENER  
TO JOIST AS REQUIRED BY  
BUILDING CODE OR E.O.R.

(2) #10-16 SCREW,  
(1) AT EACH FLANGE  
AT EACH JOIST

CEMCO SSTS RIM-TRACK  
PER PLAN

(3) #10 -16 SCREWS  
THROUGH TAB TO  
EACH JOIST

ATTACH JOIST FLANGE TO  
TOP OF WALL AS REQUIRED  
BY BUILDING CODE OR E.O.R.

CONCRETE/MASONRY/  
INSULATED CONCRETE  
FORMS (ICF) WALL  
(BY OTHERS)

CEMCO SSCJ FLOOR  
JOIST PER PLAN

10"  
MIN,  
TYP.

