



CONCRETE/MASONRY WALL  
(BY OTHERS)

ATTACH RIM-TRACK TO  
CONCRETE/MASONRY WALL  
AS REQUIRED BY BUILDING  
CODE OR E.O.R.

(3) #10 -16 SCREWS  
THROUGH TAB TO  
EACH JOIST

CEMCO SSCJ FLOOR JOIST  
PER PLAN

LEDGER STEEL  
MEMBER  
(BY OTHERS)

P.D.F.'S ATTACH  
RIM-TRACK TO TOP OF  
STRUCTURAL MEMBER AS  
REQUIRED BY BUILDING  
CODE OR E.O.R

CEMCO SSTS RIM-TRACK  
PER PLAN

(1) #10-16 SCREW  
TOP FLANGE AT EACH  
JOIST

3 1/2"  
MIN

10"  
MIN,  
TYP.