

PIECE OF CEMCO STUD OR TRACK WEB STIFFENER, 3/8" SHORTER THAN DEPTH OF JOIST AS REQUIRED BY BUILDING CODE OR E.O.R

CEMCO SSCJ FLOOR JOISTS PER PLAN

ATTACH BACK-TO-BACK CEMCO SSTS RIM-TRACK AS REQUIRED BY BUILDING CODE OR E.O.R

(1) #10-16 SCREW TOP FLANGE AT EACH JOIST

CEMCO SSCJ FLOOR JOISTS

ANCHOR RIM-TRACK TO STEEL MEMBERS AS REQUIRED BY BUILDING CODE OR E.O.R

10" MIN, TYP.  
3 1/2" MIN

SCREW ATTACH, WEB STIFFENER TO JOIST AS REQUIRED BY BUILDING CODE OR E.O.R

WALL STUDS, ALIGN WITH JOIST

