



(2) #10-16 SCREW,  
(1) AT EACH FLANGE  
AT EACH JOIST

SCREW ATTACH, WEB  
STIFFENER TO JOIST AS  
REQUIRED BY BUILDING  
CODE OR E.O.R.

(3) #10 -16 SCREWS  
THROUGH TAB TO  
EACH JOIST

CEMCO SSTS RIM-TRACK  
PER PLAN

10"  
MIN,  
TYP.     3 1/2"  
MIN

ATTACH FLANGE OF JOIST  
TO TOP OF WALL AS  
REQUIRED BY BUILDING  
CODE OR E.O.R.

PIECE OF CEMCO STUD  
OR TRACK WEB STIFFENER,  
3/8" SHORTER THAN DEPTH  
OF JOIST AS REQUIRED BY  
BUILDING CODE OR E.O.R.

CEMCO SSCJ FLOOR  
JOISTS PER PLAN

WALL STUDS, ALIGN WITH  
JOISTS